








TAYLOR TIPS

 MODEL C602



Maintenance Parts

Do you have everything you need to properly maintain your Taylor C602? If you are missing any of these parts, please contact your local Taylor distributor. It is essential that you use the below list of accessories for properly maintaining your Taylor C602.

PART DESCRIPTION	FUNCTION	TAYLOR PART NUMBER
BRUSH KIT	Used for cleaning and sanitizing the machine. Parts require brush cleaning to remove film and milk stone buildup.	X44127 
WASH BOTTLE	Used to flush and sanitize the freezer door spouts, syrup ports, and syrup fittings.	044818 
SYRUP PLUG KIT	Seals syrup port in the shake freezer door when the syrup valves are not installed. <i>Examples: a) Machine is in the heat treatment cycle</i> <i>b) Optional shake flavor is not being served.</i> Plug Kit includes: 4 hole plugs, 4 o-rings, and 1 seal install kit	X58474 
VALVE CAP ASSEMBLY	The insulated cap is installed on the shake freezer door spout during the heat treatment cycle in order to achieve the required mix temperature inside the door. (Requires part #041923 o-ring)	X54704 041923 
SYRUP CALIBRATION CUP	Used to calibrate the syrup dispensing rate. Always use the small chamber of the cup when calibrating syrups. Calibrate all syrup flavors to 1 fluid ounce (+/- 1/8 ounce).	017203 
HP LUBRICANT	Hi-Performance lubricant used specifically for machines with a 14 day brush clean cycle	048232 
EX LUBE	Hi-Performance lubricant used specifically for Heat Treatment machines with a 28-day brush clean cycle	088977 



Scan the QR code for additional resources